

B&C Reset Puffers

100% Recycled Polyester & Nylon



B&C Reset Puffer



B&C Reset Bodywarmer

SCREEN PRINTING

Plastisol or polyester inks + anti-migration layer

TRANSFER

Vinyl/Nylon flex or DTF for outerwear

EMBROIDERY

Choose flat zones to avoid interference with stitching

Not suitable for:

DTG, sublimation

GENERAL DECORATION TIPS FOR ALL B&C RESET OUTERWEAR

1. Always test your chosen method before full production.
2. Use anti-migration layers when printing or transferring.
3. Avoid printing over seams, zippers, or quilting.
4. Adjust temperature and pressure to avoid fabric shine or distortion.
5. Use specialised DTF for outerwear.

Disclaimer: These recommendations are based on B&C's internal print tests. Results may vary depending on equipment, inks, and settings used. Always run your own test to ensure optimal results.



Made from
RECYCLED MATERIALS



GENDER-NEUTRAL

